
Practica 3.1

KaAm=1

Am= 1 para todas las mediciones




Ka = 1

Ac = 46mV

 $\Delta R = 43mV$


inidice de modulación (μ) = $\frac{\Delta R}{Ac}$ = 0,94



$$Potencia\ señal\ (Ps) = \frac{Ac^2}{2}\ [1 + \frac{Ka^2 * Am^2}{2}]$$

$$(Ps) = \frac{(46m)^2}{2} \left[1 + \frac{(1)^2 * (1)^2}{2} \right] = 1.587 \, mW$$

Para KaAm < 1




$$Ka = 0.5$$

$$Ac = 46mV$$

$$\Delta R = 23mV$$


inidice de modulación (µ) =
$$\frac{\Delta R}{Ac}$$
 = 0,5



Potencia señal (Ps) =
$$\frac{Ac^2}{2} \left[1 + \frac{Ka^2 * Am^2}{2}\right]$$

$$(Ps) = \frac{(46m)^2}{2} \left[1 + \frac{(0.5)^2 * (1)^2}{2} \right] = 1.19025 \, mW$$

Para KaAm > 1



Ac = 46mV

 $\Delta R = 88mV$

inidice de modulación (μ) = $\frac{\Delta R}{Ac}$ = 1,92



Potencia señal (Ps) =
$$\frac{Ac^2}{2} \left[1 + \frac{Ka^2 * Am^2}{2}\right]$$

$$(Ps) = \frac{(46m)^2}{2} \left[1 + \frac{(2)^2 * (1)^2}{2} \right] = 3.174 \, mW$$